

Four things Walther does on a shipped machine

The power connection your machine leaves the shop with: split for shipping, disconnected at the frame, and listed as an assembly so the field has nothing to build. Built in Somerset, New Jersey.



1 The machine splits here

Procon rectangular connectors carry power and control through one hood. Sections ship separately, **mate the inserts, snap the hood, energize** on the customer's floor. Washdown versions to IP68.



2 Connect, disconnect, lock out: one part

The receptacle and the switch are one unit on the frame: the circuit cannot be made or broken under load, and the handle takes a lock. **The disconnect ships with the machine**, IP67 where the water hits.



3 The cord ships with the machine

Cord sets and custom cable assemblies, plug landed, cut to your length, **the listing carried by the assembly**. The customer's electrician lands one plug, not a set of conductors.



4 One inlet, breaker-protected branches

Distribution assemblies with breaker protection built in, shipped wired and ready, so a multi-section machine takes **one incoming feed** and hands each section its own protected branch.

Wrote the original IEC 60309 standard

Every pin and sleeve device is interchangeable with any conforming maker worldwide.

UL Listed and CSA Certified together

Series II ratings 20/30/60/100 A at 125/250/277/480 V. One part number covers a machine shipped to a US or a Canadian customer.

US operation ISO 9001:2015

The Somerset, NJ assembly shop holds its own certification (TUV Rheinland, July 2026), a qualified supplier of record.